

1903500  
1515

# FastMig

MS 200, MS 300



# **OPERATING MANUAL**

**English**

## CONTENTS

1.	Preface.....	3
1.1	General.....	3
2.	Use.....	4
2.1	Connecting and mounting the panels.....	4
2.2	Functions of MS 200 and MS 300 panels.....	5
2.3	MS 200 and MS 300 operations .....	6
2.4	Additional welding functions.....	9
2.5	FastMig welding programs.....	11
2.6	Panel MS 200 and MS 300 setup parameters.....	14
3.	FastMig error codes.....	18
4.	Disposal.....	19
5.	Ordering numbers.....	19

EN

# 1. PREFACE

## 1.1 General

Congratulations on choosing the MS panel. Used correctly, Kemppi products can significantly increase the productivity of your welding, and provide years of economical service.

This operating manual contains important information on the use, maintenance and safety of your Kemppi product. The technical specifications of the equipment can be found at the end of the manual.

Please read the manual carefully before using the equipment for the first time. For your own safety and that of your working environment, pay particular attention to the safety instructions in the manual.

For more information on Kemppi products, contact Kemppi Oy, consult an authorised Kemppi dealer, or visit the Kemppi web site at [www.kemppi.com](http://www.kemppi.com).

The specifications presented in this manual are subject to change without prior notice.

### **Important notes**

Items in the manual that require particular attention in order to minimise damage and personal harm are indicated with the **'NOTE!'** notation. Read these sections carefully and follow their instructions.


### **Disclaimer**

While every effort has been made to ensure that the information contained in this guide is accurate and complete, no liability can be accepted for any errors or omissions. Kemppi reserves the right to change the specification of the product described at any time without prior notice. Do not copy, record, reproduce or transmit the contents of this guide without prior permission from Kemppi.

## 2. USE


FastMig MS 200 and MS 300 control panels are designed to be used only with synergic power sources FastMig M 320, 420, or 520. MS 200 panel can be mounted to MXF 63 (200 mm wire spool) wire feeder and MS 300 panel to MXF 65 and 67 (300 mm wire spool) wire feeders.

### 2.1 Connecting and mounting the panels




Fasten the ribbon cable connector from the MXF wire feed unit to the function panel.

#### MXF 65



1. Place the bottom edge of the panel behind the securing clips on the machine. Remove the fixing pin from the top edge with, for example, a screwdriver. Then gently push the upper part of the panel into place. Make sure that the cables do not get damaged, continue gently pushing the upper part of the panel until it clips into place.
2. Finally secure the panel into place with the additional black plastic security clip provided (MXF 65 only). Ensure that the clip is positioned correctly. You will notice that the clip does not seat snugly if it's positioned upside down.


#### MXF 63 + MXF 67



MXF 63

MXF 67

## 2.2 Functions of MS 200 and MS 300 panels



1. ON/OFF button
  2. Memory channels for welding parameters (short press selects, long press saves)
  3. a) Wire feed speed/welding current/sheet thickness display  
b) Selected SETUP entry display
  4. a) Adjustment of wire feed speed  
b) Adjustment of welding power setting 1-MIG/WiseRoot/WiseThin \*\*  
c) Adjustment of MMA current  
d) Selection of SETUP parameter  
e) Selection of 1-MIG/WiseRoot/WiseThin welding program (material group) \*\*
  5. a) Selection of switching logic: 2T/4T/4T Minilog \*  
b) Long press: Setting the basic parameters (SETUP)
  6. a) 1-MIG/WISE synergic welding program check \*\*  
b) 1-MIG/WISE synergic welding program selection (long press) \*\*
  7. a) Welding voltage display  
b) Adjustable parameters display
  8. a) Welding voltage adjustment  
b) Adjustment of length of welding arc (1-MIG)  
c) Adjustment of MIG dynamics  
d) Adjustment of SETUP parameter  
e) Selection of 1-MIG/WiseRoot/WiseThin welding program (program number) \*\*  
f) WiseRoot and WiseThin base current adjustment \*\*
  9. Selection LED indicators for synergic welding program – indicators for material, wire thickness and gas type
  10. Selection of MIG/1-MIG/MMA welding process
  11. a) Selection of additional MIG functions  
b) Weld data: Show last used welding parameters in displays (long press)
  12. Manual control/remote control unit selection (long press for channel remote usage)
  13. MIG dynamics/MMA Arc Force/Wise Forming Pulse selection \*\*
  14. Display of air/liquid cooled MIG gun (selection from setup)
- \*) Minilog is not included in standard delivery.  
\*\*) Wise products are available as optional welding process solutions. Not included in the standard delivery. Please visit [www.kemppi.com](http://www.kemppi.com) or Kemppi Datastore.

**NOTE!** With MS 200 and MS 300 panels 'Wire Inch' and 'Gas Test' buttons should be used from the inside of the wire feed unit.

## 2.3 MS 200 and MS 300 operations

### ON/OFF button (1)



The wire feed unit remains in the OFF position when the power source is switched on, thus preventing start-up. 'OFF' is shown on the display.

When the ON/OFF button is pressed for more than 1 second, the unit starts up. The unit is now ready for welding and will automatically return back to its previous position, before the power was cut off. The wire feed unit starts up also by pressing three (short) times the switch of the welding gun.

### Basic settings and displays

With MIG welding the wire feed speed is set via left potentiometer (control knob) and the value is shown on the left display. The welding voltage is set via right potentiometer (control knob) and the value is shown on the right display. During welding, the left display shows the actual welding current value and the display on the right shows the welding voltage.

With electrode welding (MMA) the welding current value is set via the potentiometer and the value is shown on the left display. The display on the right shows the idling voltage of the power source. During welding the left display shows the actual welding current value and the display on the right shows the welding voltage.

When MIG dynamics/electrode welding Arc force adjustment is activated with Arc Force/Dynamics button the value is adjusted via right potentiometer (control knob) (see the information on adjustment of MIG dynamics/arc force).

With Synergic 1-MIG welding, the power value is set via left potentiometer (control knob) and the length of the arc via right potentiometer (control knob) (see '1-MIG welding').

### Adjustment of MIG dynamics/Arc Force (13)



With MIG welding dynamics adjustment is influenced on welding stability and spatter amount. Zero setting is recommended basic setting. Values  $\rightarrow$  min (-1 ... -9), softer arc for reduced spatter amount. Values  $\rightarrow$  max (1 ... 9), harder arc for increased stability and when 100 % CO<sub>2</sub> shielding gas is used when welding steel.

With electrode welding Arc Force adjustment is influenced on welding stability. Adjustment is needed for using different types of electrodes. Control range (-9 ... 0) is commonly used for welding electrodes for stainless steel. Control range (0 ... +9) is used for harder arc characteristic to increase stability, e.g. for welding with thicker basic electrodes and using lower current value than recommended. Factory set value (0) is a good general use for adjusting the roughness of the arc.

### Indication of liquid-cooled MIG gun (14)



You can activate either air or liquid cooled MIG gun with a setup parameter. For more information, see chapter 2.6.

If the LED (14) is lit, liquid-cooling is activated in the system. In this case, ensure that you have connected a liquid-cooled MIG gun to the equipment. The cooling units starts on the next machine startup.

## Weld data (11)



The weld data function is activated by long-pressing the additional welding functions button. The weld data function returns the welding current and voltage values to the displays that were in use during the last weld.

## Selection of welding process (10)



The welding process – normal MIG or 1-MIG – can be chosen with the welding process selection button. In normal MIG welding wire feed speed and welding voltage is adjusted separately. In synergic 1-MIG and Wise welding the welding voltage and other parameters related to welding are optimally bound to each other! In synergic welding the setting for power and arc length are adjusted.

Electrode welding (MMA) is selected by pressing the button for >1 second. When electrode welding is selected, the power source, the electrode holder connected to it and the MIG gun become energised (open circuit voltage).

LED indicators: **MMA** (MMA selected), **MIG** (MIG selected), **1-MIG** (1-MIG selected), **1-MIG + WISE** (1-MIG and either WiseFusion or WisePenetration selected, selection between the two is done through SETUP) and **WISE** (WiseRoot or WiseThin selected, selection between the two is done through welding program selection).

WiseRoot/WiseThin program is activated by choosing a WiseRoot/WiseThin welding program (WISE led then turns on). Wise welding is the facility provided separately, so the function is not in every equipment. WiseRoot and WiseThin require licences, which can be purchased in Kemppi DataStore.

## Selection of MIG operating procedure (5)

- 2T
- 4T
- MINILOG



MIG 2T: MIG welding with two-sequence procedure of welding gun start switch

1. switch pressed: welding starts
2. switch released: welding stops

MIG 4T: MIG welding with four-sequence procedure of welding gun start switch

1. switch pressed: shielding gas flow starts
2. switch released: welding starts
3. switch pressed: welding stops
4. switch released: shielding gas flow stops

Minilog: Minilog is an additional function, which can be purchased separately. (Minilog is also referred as 'Matchlog' in DataStore.)

Without Minilog license, press of the button chooses between 2T and 4T.

## Setup (5)



When the adjustment of SETUP parameters has been confirmed with a long press of the SETUP button (10), the adjustable parameter is selected via left potentiometer (control knob) and the name of the parameter is shown on the left display. The parameter's value is set via right potentiometer (control knob) and the value is shown on the display on the right (see 'SETUP functions').

## Synergic 1-MIG or Wise welding (6, 10)



In Synergic 1-MIG welding, the optimal welding parameters for the welding wires and gas used are recorded in the unit. The welding is controlled by adjusting the welding power and arc length.

Wise processes are additional functions, which can be purchased separately.

### Welding program selection:

Before starting to weld, a welding program suitable for the welding wire and gas used must be chosen based on this Operating Manual.

Welding program selection is activated by pressing Set Prog button longer than one second. In this case both displays begin to flash and the material group is selected with the control knob on the left and the welding program for the material group in question with the control knob on the right.

First five material groups are for Synergic 1-MIG welding and last five are for Wise processes.

Refer to the selection LED indicators on the panel for synergic welding program – indicators show the material, the wire thickness and the gas type in question.

The selected programme is immediately recorded in the memory. To get back to normal status press ON/OFF (1) key, or Set Prog button (6).


### Use of a selected welding program:

The selected welding program is immediately ready for welding. Check that the welding program corresponds to the welding wire and shield gas in use. The selection LED indicators on the panel show the material, the wire thickness and the gas type in use. The welding program number can be checked by briefly pressing the Set Prog button (6), after which the displays show the welding program number.

*TIP!* The selected welding program can be saved for later use using one of the memory channels. Refer to 'Memory functions'.

Set the desired welding power via the left-hand potentiometer (control knob) and the arc length via the potentiometer (control knob) on the right.

## Memory functions (2)



### Storage of settings

The memory functions can be used to record useful welding values in the memory. There are five different memory channels under five separate memory buttons: 1 ... 5.

In addition to welding values (wire feed speed, welding voltage), function options such as 2T/4T, Creep Start, and Crater Level are recorded in the memory as well as the used welding program.

Short press selects the memory locations.

Long press saves the current settings to the selected memory location.

### Use of stored settings

Short press selects the memory locations.

#### Remote Selection Button (12)



Short Press: Gun Remote/Hand Remote selection. If remote auto recognition is selected ON only those remote controls which can be found are selected.

Long Press: CH remote function ON/OFF. Gun Remote or Hand Remote control must be selected first before CH remote function can be turned ON/OFF. When active, CH remote LED is lit and memory channels are selectable from the remote control device.

The CH remote function enables selection of memory channels via the selection controller located on the gun.

## 2.4 Additional welding functions


#### Activation with the MIG function selection button (11)



The selection button for additional MIG functions can be used to activate the Hot Start or the Crater Fill function. Further presses of the selection button can select one or more of the above functions. Only the available additional functions for each method can be selected.

- **HotStart function** is meant to reduce initial welding errors when welding highly heat-conductive materials such as aluminium. Hot Start can be selected when using Synergic 1-MIG welding and when the 4T operating mode is selected. In this case, when the start switch of the gun is held down, a fixed pre-gas time is displayed after which welding starts at the level determined by the SETUP mode's Hot Start parameter, returning to the normal level when the gun switch is released.
- **Crater Fill** is meant to reduce welding defects caused by end cratering. The Crater Fill function can be selected when using Synergic 1-MIG welding and when the 4T operating mode is selected. When the gun switch is pressed down in connection with termination of welding, the welding power drops to the crater-filling level selected previously. The crater filling function is discontinued by releasing the gun switch.

**NOTE!** In crater fill, the initial value of the welding power must be greater than the final value, and therefore the adjustment ranges for the initial and final values are restricted automatically, if necessary.



Parameters related to these functions are set via the SETUP function (see 'SETUP functions').

Stopping is performed as with the normal 4T function.

The values of parameters related to additional MIG functions can be changed with the SETUP function (see 'SETUP').

Parameters are selected for adjustment via potentiometer on the left. The value of the parameter is set via potentiometer on the right. The value is immediately recorded in the memory.

### Activation through SETUP

Other additional MIG functions are activated through SETUP.

- **Creep Start** is meant to facilitate the initial weld – e.g., when welding with a high wire feed speed. The wire feed speed is kept low until the wire touches the work piece and the current begins to flow. Creep Start can be selected with normal MIG welding or with Synergic 1-MIG welding.
- **WiseFusion™** is a welding function for ensuring consistent weld quality in all positions. It is an optional feature, which can be purchased through Kemppi DataStore.
- **WisePenetration™** is a welding function for delivering constant welding power regardless of changes in the stick out length. It is an optional feature, which can be purchased through Kemppi DataStore.
- **MatchLog™** contains **MiniLog™** function for quickly changing welding parameters on the run. It is an optional feature, which can be purchased through Kemppi DataStore.
- If your welding needs change and you wish to update your system in the future, you can order additional welding programs or other welding software and load them to your system with **Kemppi DataGun** field programming device.

For further information about the available welding programs, modified processes and special enhanced arc performance solutions, visit Kemppi web site at [www.kemppi.com](http://www.kemppi.com) or contact the local Kemppi dealer.

## 2.5 FastMig welding programs

1-MIG (Standard welding programs)			
Fe group	Wire (mm)	Material	Shielding gas
101	0.8	Fe	Ar+18%-25%CO <sub>2</sub>
102	0.9	Fe	Ar+18%-25%CO <sub>2</sub>
103	1.0	Fe	Ar+18%-25%CO <sub>2</sub>
104	1.2	Fe	Ar+18%-25%CO <sub>2</sub>
106	1.6	Fe	Ar+18%-25%CO <sub>2</sub>
111	0.8	Fe	CO <sub>2</sub>
112	0.9	Fe	CO <sub>2</sub>
113	1.0	Fe	CO <sub>2</sub>
114	1.2	Fe	CO <sub>2</sub>
116	1.6	Fe	CO <sub>2</sub>
121	0.8	Fe	Ar+8%CO <sub>2</sub>
122	0.9	Fe	Ar+8%CO <sub>2</sub>
123	1.0	Fe	Ar+8%CO <sub>2</sub>
124	1.2	Fe	Ar+8%CO <sub>2</sub>
126	1.6	Fe	Ar+8%CO <sub>2</sub>
152	0.9	Fe Metal	Ar+18%-25%CO <sub>2</sub>
154	1.2	Fe Metal	Ar+18%-25%CO <sub>2</sub>
164	1.2	Fe Metal	CO <sub>2</sub>
174	1.2	Fe Rutil	Ar+18%-25%CO <sub>2</sub>
184	1.2	Fe Rutil	CO <sub>2</sub>
194	1.2	Fe Basic	Ar+18%-25%CO <sub>2</sub>
Ss group	Wire (mm)	Material	Shielding gas
201	0.8	CrNiMo 19 12	Ar+2%CO <sub>2</sub>
202	0.9	CrNiMo 19 12	Ar+2%CO <sub>2</sub>
203	1.0	CrNiMo 19 12	Ar+2%CO <sub>2</sub>
204	1.2	CrNiMo 19 12	Ar+2%CO <sub>2</sub>
206	1.6	CrNiMo 19 12	Ar+2%CO <sub>2</sub>
211	0.8	CrNiMo 19 12	Ar+30%He+1%O <sub>2</sub>
212	0.9	CrNiMo 19 12	Ar+30%He+1%O <sub>2</sub>
213	1.0	CrNiMo 19 12	Ar+30%He+1%O <sub>2</sub>
214	1.2	CrNiMo 19 12	Ar+30%He+1%O <sub>2</sub>
216	1.6	CrNiMo 19 12	Ar+30%He+1%O <sub>2</sub>
221	0.8	CrNi 23 12	Ar+2%CO <sub>2</sub>
222	0.9	CrNi 23 12	Ar+2%CO <sub>2</sub>
223	1.0	CrNi 23 12	Ar+2%CO <sub>2</sub>
224	1.2	CrNi 23 12	Ar+2%CO <sub>2</sub>
231	0.8	CrNi 23 12	Ar+30%He+1%O <sub>2</sub>
232	0.9	CrNi 23 12	Ar+30%He+1%O <sub>2</sub>
233	1.0	CrNi 23 12	Ar+30%He+1%O <sub>2</sub>
234	1.2	CrNi 23 12	Ar+30%He+1%O <sub>2</sub>
242	0.9	FC-CrNiMo 19 12	Ar+18%-25%CO <sub>2</sub>
244	1.2	FC-CrNiMo 19 12	Ar+18%-25%CO <sub>2</sub>

252	0.9	FC-CrNiMo 19 12	CO <sub>2</sub>
254	1.2	FC-CrNi 23 12	Ar+18%-25%CO <sub>2</sub>
<b>Al group</b>	<b>Wire (mm)</b>	<b>Material</b>	<b>Shielding gas</b>
303	1.0	AlMg5	Ar
304	1.2	AlMg5	Ar
306	1.6	AlMg5	Ar
313	1.0	AlSi5	Ar
314	1.2	AlSi5	Ar
316	1.6	AlSi5	Ar
<b>SPE group</b>	<b>Wire (mm)</b>	<b>Material</b>	<b>Shielding gas</b>
401	0.8	CuSi3	Ar
402	0.9	CuSi3	Ar
403	1.0	CuSi3	Ar
404	1.2	CuSi3	Ar
411	0.8	CuSi3	Ar+2% CO <sub>2</sub>
412	0.9	CuSi3	Ar+2% CO <sub>2</sub>
413	1.0	CuSi3	Ar+2% CO <sub>2</sub>
421	0.8	CuAl8	Ar
423	1.0	CuAl8	Ar
424	1.2	CuAl8	Ar

WiseRoot (Standard welding programs when WiseRoot is activated *)				
Fe group	Wire (mm)	Material	Shielding gas	
802	0.9	Fe	Ar+18%-25%CO <sub>2</sub>	
803	1.0	Fe	Ar+18%-25%CO <sub>2</sub>	
804	1.2	Fe	Ar+18%-25%CO <sub>2</sub>	
Ss group	Wire (mm)	Material	Shielding gas	Backing gas
822	0.9	CrNiMo 19 12	Ar+2%CO <sub>2</sub>	Ar
823	1.0	CrNiMo 19 12	Ar+2%CO <sub>2</sub>	Ar
824	1.2	CrNiMo 19 12	Ar+2%CO <sub>2</sub>	Ar
832	0.9	CrNiMo 19 12	Ar+30%He+1%O <sub>2</sub>	Ar
833	1.0	CrNiMo 19 12	Ar+30%He+1%O <sub>2</sub>	Ar
834	1.2	CrNiMo 19 12	Ar+30%He+1%O <sub>2</sub>	Ar

WiseThin (Standard welding programs when WiseThin is activated *)				
Fe group	Wire (mm)	Material	Shielding gas	Backing gas
701	0.8	Fe	Ar+18%-25%CO <sub>2</sub>	
702	0.9	Fe	Ar+18%-25%CO <sub>2</sub>	
703	1.0	Fe	Ar+18%-25%CO <sub>2</sub>	
704	1.2	Fe	Ar+18%-25%CO <sub>2</sub>	
711	0.8	Fe	CO <sub>2</sub>	
712	0.9	Fe	CO <sub>2</sub>	
713	1.0	Fe	CO <sub>2</sub>	
714	1.2	Fe	CO <sub>2</sub>	
Ss group	Wire (mm)	Material	Shielding gas	Backing gas
721	0.8	CrNiMo 19 12	Ar+2%CO <sub>2</sub>	Ar
722	0.9	CrNiMo 19 12	Ar+2%CO <sub>2</sub>	Ar
723	1.0	CrNiMo 19 12	Ar+2%CO <sub>2</sub>	Ar
724	1.2	CrNiMo 19 12	Ar+2%CO <sub>2</sub>	Ar
Cu group	Wire (mm)	Material	Shielding gas	Backing gas
743	1.0	CuSi3	Ar	
753	1.0	CuAl8	Ar	

\*) WiseRoot and WiseThin welding processes are not included in the standard delivery. They are available as optional welding process solutions. Please visit [www.kemppi.com](http://www.kemppi.com) or Kemppi Datastore.

**NOTE!** More welding programs are available in Kemppi DataStore.

## 2.6 Panel MS 200 and MS 300 setup parameters

### Normal MIG welding Setup -parameters

Name of parameter	Name on display	Parameter values	Factory setting	Description
Pre Gas Time	PrG	0.0 – 9.9 s	0,0 s	Pre gas time in seconds
Post Gas Time	PoG	0.0 – 9.9 s	Aut	Post gas time in seconds or automatically according to welding current (Aut)
Creep Start	Cr	OFF, on	OFF	Switch creep start on or off.
Creep Start Level	CrE	10 – 170%	50%	Percentage of wire feed speed: 10% slowed start 100% = no creep start function 170% accelerated start
Start Power	StA	-9 ... +9	0	Strength of start pulse
Post Current Time	PoC	-9 ... +9	0	Post current
Arc Voltage	Ard	OFF, on	OFF	on: Display shows arc voltage OFF: Display shows pole voltage
Cable Length	CAB	std, 5 – 80m	std	Cable loss is calculated for optimal arc control and for the Arc Voltage display

### Synergic MIG -welding SETUP -parameters

Name of parameter	Name on display	Parameter values	Factory setting	Description
Pre Gas Time	PrG	0.0 – 9.9 s	Syn	Pre gas time in seconds or automatically according to synergic welding program (Syn)
Post Gas Time	PoG	0.0 – 9.9 s	Syn	Post gas time in seconds or automatically according to synergic welding program (Syn)
Creep Start	Cr	OFF, on	OFF	Switch creep start on or off.
Creep Start Level	CrE	10 – 170%	50%	Percentage of wire feed speed: 10% slowed start 100% = no creep start function 170% accelerated start
Hot Start Level	Hot	-50 ... 75%	30%	Percentage of welding power: -50% cold and +75% hot
Hot Start 2T Time	H2t	0.0 – 9.9 s	1.2 s	The duration of the hot start in seconds in 2T mode
Crater Fill End Level	CrL	10 – 250%	30%	The welding power at the end of the crater fill stage as a percentage of the welding power preset value
Crater Fill Start Level	CrS	10 – 250%	30%	The welding power at the beginning of the crater fill stage as a percentage of the welding power preset value
Crater Fill Time	CrT	0.0 – 9.9 s	2.0 s	The duration of the crater fill stage in seconds (only in 2T mode)
Wise Fusion On	FUS	OFF, on	OFF	Switch Wise Fusion on/off (only in 1-MIG)
Wise Fusion Percent	FUP	10...60%	25%	Percentage of Wise Fusion (only in 1-MIG)
Wise Penetration On	PE	OFF, on	OFF	Switch Wise Penetration on/off (only in 1-MIG)
Penetration Level	PEn	-30 ... +30%	0%	Set the arc length where penetration control begins (only in 1-MIG)
MiniLog On	ML	on, OFF	OFF	Switch on/off MiniLog

<b>MiniLog Level</b>	MLo	-99 ... +200%	50%	Set the minilog power level as a percentage of the welding power
<b>Synergic Start Time</b>	FSt	-9 ... +9	0	Star time in WiseRoot/WiseThin welding
<b>Synergic Start Voltage</b>	FuL	-30 ... +30	0	Voltage level in the beginning of WiseRoot/WiseThin welding
<b>Start Power</b>	StA	-9 ... +9	0	Strength of start pulse (not in WiseRoot or WiseThin)
<b>Post Current Time</b>	PoC	-9 ... +9	0	Post current
<b>Synergic MIG Unit</b>	Unl	m/min, mm, A	m/min	In 1-MIG and WiseRoot welding, the parameter shown in left-hand display: wire feed speed (m/min), sheet thickness (mm) or average current (A)
<b>Arc Voltage</b>	Ard	OFF, on	OFF	on: Display shows arc voltage OFF: Display shows pole voltage (not in WiseRoot or WiseThin)
<b>Cable Length</b>	CAb	std, 5 – 80m	std	Cable loss is calculated for optimal arc control and for the Arc Voltage display (not in WiseRoot or WiseThin)

### Common Setup -parameters for MIG processes

Name of parameter	Name on display	Parameter values	Factory setting	Description
Device Address	Add	3 or 6	3	Wire feeder bus address
Using features of PMT Gun	Gun	OFF, on	on	on = PMT gun OFF = other gun
Gas Guard Connected	GG	no, YES	no	Implementation of gas guard
LongSystem Mode	LSY	OFF, on	OFF	on: Gives optimum welding characteristics with long welding cables. Recommended to be used when the cable length exceeds 40 m.
Code Entry	Cod	---, Ent	---	Entering license codes manually: 1. Adjust right potentiometer to ('Ent'). 2. Press REMOTE. 3. Set code with right potentiometer. 4. Choose next with left potentiometer. 5. Go back to point 3, until all codes have been set. 6. Approve by pressing REMOTE. ('Suc cEs')
PIN Code Entry	Pln	---, Pln	---	Enters pin code for Panel Locking
Panel Locking	LoC	OFF, on	OFF	Enables panel locking
Water Cooler	Coo	OFF, on	on	Enables water cooler
Wire Inch Stop	Inc	OFF, on	on	OFF = Stops wire inch in case arc does not ignite on = Feeds wire as long as the welding gun start switch is pressed.
Auto Wire Inch	Aln	OFF, on	on	SuperSnake Automatic Wire Inch function. Wire Inch button runs the filler wire from the wire feeder up to the SuperSnake.
Demo Licence Time	dEt	3-h, 2-h, **, ***, OFF		The remaining time for the WiseDemo licence (readable value only). 3-h = max. 3 hours left 2-h = max. 2 hours left **' = ** minutes left **" = ** seconds left OFF = Demo period has expired.
Restore Factory Settings	FAC	OFF, PAn, ALL	OFF	Control panel reset function. OFF = No reset PAn = Settings will be restored, but memory channels remain unchanged ALL = All settings will be restored to factory values.

### Setup-parameters for MMA welding

Name of parameter	Name on display	Parameter values	Factory setting	Description
Start Power	StA	-9 ... +9	0	Strength of start pulse
Device Address	Add	3 or 6	3	Wire feeder bus address
Code Entry	Cod	---, Ent	---	Entering license codes manually: 1. Adjust right potentiometer to ('Ent'). 2. Press REMOTE. 3. Set code with right potentiometer. 4. Choose next with left potentiometer. 5. Go back to point 3, until all codes have been set. 6. Approve by pressing REMOTE. ('Suc cEs')
Restore Factory Settings	FAC	OFF, PAn, ALL	OFF	Control panel reset function. OFF = No reset PAn = Settings will be restored, but memory channels remain unchanged ALL = All settings will be restored to factory values

**NOTE!** In these setup lists following functions needs activation (Err 171):

- Minilog
- Panel Locking
- WisePenetration
- WiseFusion

### 3. FASTMIG ERROR CODES

The existence of possible faults in the equipment is investigated in connection with each wire feed unit start-up. If a fault is detected, the fault in question will be indicated as an 'Err' message on the panel display.

#### **Error code examples:**

##### **Err 2: Undervoltage**

The device has stopped because it has detected a mains undervoltage that disturbs welding. Check the quality of the supply network.

##### **Err 3: Overvoltage**

The device has stopped because dangerously high temporary voltage surges or a continuous over-voltage has been detected in the electric network. Check the quality of the supply network.

##### **Err 4: Power source is overheated**

The power source has overheated. The cause may be one of the following:

- The power source has been used for a long time at maximum power.
- The circulation of cooling air to the power source is blocked.
- The cooling system has experienced a failure.

Remove any obstacle to air circulation, and wait until the power source fan has cooled down the machine.

##### **Err 5: Water unit alarm**

The water circulation is blocked. The cause may be one of the following:

- Congestion or disconnection in the cooling pipeline
- Insufficient cooling liquid
- Excessive cooling liquid temperature

Check the circulation of the cooling liquid and the air circulation of the water unit.

##### **Err 54: No data communication from power source**

The data transmission between the power source and the wire feed unit has been cut off or is defective. Check the extension lead and connections.

##### **Err 55: Power source is busy**

The communication channel is busy. The power source is being used by another wire feed unit or the programming for some other device in the channel (e.g. control panel) is in progress.

##### **Err 61: The water unit is not found**

Water unit is not connected to the equipment or there is a connection fault.

Connect up the water unit or change the setting of the unit to air-cooled, if you are using a air-cooled welding gun.

##### **Err 153: Overheating of liquid-cooled PMT gun**

When starting to weld or during welding, the overheat protection on the liquid-cooled MIG welding gun has activated. Check that there is sufficient liquid in the cooling unit and that air is circulating freely through it. Ensure that liquid is circulating freely through the cooling hoses.

##### **Err 154: Overloading of the wire feed motor**

The welding has been interrupted because the loading of the wire feed motor has risen to a high level. The cause of this could be a blockage of the wire line. Check the wire conduit, contact tip and feed rolls.

##### **Err 155: Warning of the wire feed unit overloading**

The wire feed motor load level has risen. The cause could be dirty wire conduits or a gun cable twisted into sharp curves. Check the state of the gun and clean the wire line if necessary.

##### **Err 165: Gas guard alarm**

Gas guard function has worked, because the pressure of gas has decreased. Possibly reasons: Gas is unconnected to the wire feeder. Gas has been ran out, gas hose is leaking or there is no pressure enough in the gas web. Connect the gas to the wire feeder, check gas hose and the pressure of the gas web.

**Err 171: Configuration not found for the device**

The optional features cannot be used. There is no licence code for that or the equipment's internal data transmission has been cut off. Turn off the machine, detach the welding gun and re-start the machine. If an error code does not appear in the display, the fault lies in the welding gun. If this error code pertains, contact maintenance.

**Err 172: A wrong configuration code has been supplied**

License activation with DataGun has failed. Turn off the machine, detach DataGun and restart the machine. Reconnect DataGun. If this error code recurs, contact maintenance.

**Err 201: Use of PMT gun is prevented**

You try to use the PMT welding gun, but the necessary settings have not been entered into the machine's control panel. Select 'PMT gun' from the control panel SETUP menu, if you wish to use it. This fault can also occur with other guns, if the trigger contacts are bad or dirty.

**Err 221: Two wire feeders connected with the same device address**

Two wire feed units have the same device address. Define different addresses for the devices as follows:

1. Press any button on either control panel (except the ESC button). "Add" (Device Address) is displayed.
2. Change the device address using the right-hand control knob.
3. Return to normal status by pressing again any button on the control panel.

The machines will return to normal status within 15 seconds.

**Other error codes:**

The machine can show codes not listed here. In the event of an unlisted code appearing, contact an authorised Kemppi service agent and report the error code shown.

## 4. DISPOSAL



Do not dispose of electrical equipment with normal waste!

In observance of European Directive 2002/96/EC on waste electrical and electronic equipment, and its implementation in accordance with national law, electrical equipment that has reached the end of its life must be collected separately and taken to an appropriate environmentally responsible recycling facility.

The owner of the equipment is obliged to deliver a decommissioned unit to a regional collection centre, per the instructions of local authorities or a Kemppi representative. By applying this European Directive you will improve the environment and human health.

## 5. ORDERING NUMBERS

FastMig MS 200	MXF 63	6136300
FastMig MS 300	MXF 65, MXF 67	6136400

